


PRELIMINARY VERSION

Operating Instructions
Software L-LAS-TB-Scope V2.2


(PC software for Microsoft® Windows® Vista, XP, 2000, NT® 4.0, Me, 98)

for Laser Line Sensors of the L-LAS-TB Series (V2)




Split version, e.g.

L-LAS-TB-12
L-LAS-TB-25
L-LAS-TB-35
L-LAS-TB-50
L-LAS-TB-75
L-LAS-TB-100



Fork-type version, e.g.

L-LAS-TB-F-(8)-30/40
L-LAS-TB-F-(16)-30/40



Split version with separate
electronic control unit, e.g.

L-LAS-TB-8-CON1
L-LAS-TB-8-CON2
L-LAS-TB-12-CON1

0 Table of Contents


| Chapter | Page |
|---|-----------|
| 1. Functional principle: Electronic control unit L-LAS-TB..... | 3 |
| 1.1 Technical description..... | 3 |
| 2. Installation of the <i>L-LAS-TB-Scope software</i> | 4 |
| 3. Operation of the <i>L-LAS-TB-Scope software</i> | 6 |
| 3.1 Control elements of the <i>L-LAS-TB-Scope software</i> | 7 |
| 3.2 Numeric and graphic display elements | 12 |
| 3.3 Serial RS232 data transfer | 14 |
| 3.4 <i>L-LAS-TB-Scope</i> as an aid for sensor adjustment..... | 15 |
| 3.5 <i>L-LAS-TB-Scope</i> as an aid for transmitter power adjustment..... | 16 |
| 4. Evaluation modes..... | 17 |
| 4.1 LEFT-EDGE | 17 |
| 4.2 RIGHT-EDGE | 17 |
| 4.3 WIDTH..... | 18 |
| 4.4 CENTER..... | 18 |
| 5. Two-point calibration | 19 |
| 6. Annex..... | 20 |
| 6.1 Laser warning | 20 |
| 6.2 Function of the TEACH/RESET button | 20 |
| 6.3 Function of the tolerance potentiometer..... | 20 |
| 6.4 Function of digital inputs IN0 and IN1 | 21 |
| 6.5 Connector assignment | 22 |

1 Functional principle: Electronic control unit *L-LAS-TB*

1.1 Technical description

In the laser line sensors of the *L-LAS series* the laser beam of a laser diode ($\lambda=670\text{nm}$, 1mW power, laser class 2) through suitable collimators and apertures is emitted from the optical transmitter unit as a laser line, i.e. as a parallel laser light with homogeneous light distribution. In the optical receiver unit the laser line impinges on a CCD line receiver. This CCD line comprises many closely adjacent individual receiver elements (pixels) that are arranged in a line. The light quantity of each of these receiver elements that is collected during the integration time can be separately read out as an analog voltage and, after performing analog-digital conversion, can be stored in a data field as a digital value.

When there is a non-transparent measuring object in the laser line, the parallel laser light only illuminates those receiver elements (pixels) of the line that lie outside the shadow zone of the measuring object. As a result the pixels within the shadow zone give off a considerably lower analog voltage compared to the illuminated pixels. By way of suitable software algorithms the areas of the shadow zones can be determined from the previously stored data field. Since the distance of the pixels on the CCD line is known, the size and position of the measuring object can therefore be determined. The micro-controller of the *L-LAS-TB* sensor can be parameterized through the serial RS232 interface by means of a Windows PC software. The sensor can be set to operate with different evaluation modes. The housing of the control unit features a TEACH/RESET button and a potentiometer for tolerance setting. Switching states are visualized by means of 4 LEDs (1x green, 1x yellow, and 2x red) that are integrated in the housing of the *L-LAS*-sensor. The *L-LAS-TB* control unit has three digital outputs (OUT0, OUT1, OUT2), the output polarity of which can be set with the software. Two digital inputs (IN0, IN1) make it possible to realize an external TEACH/RESET functionality and an external TRIGGER functionality through a PLC. In addition the control unit features a high-speed analog output (0 ... 10V) with 12-bit digital/analog resolution.





2 Installation of the *L-LAS-TB-Scope* software

Hardware requirements for successful installation of the *L-LAS-TB-Scope* software:

- 100 MHz Pentium-compatible processor or better.
- CD-ROM or DVD-ROM drive
- Approx. 8 MByte of free hard disk space
- SVGA graphics card with at least 800x600 pixel resolution and 256 colors or higher.
- Windows 98, Windows NT4.0, Windows 2000, or Windows XP operating system
- Free serial RS232 interface or USB port with USB-RS/232 adaptor at the PC

Please install the *L-LAS-TB-Scope* software as described below:


1.  **CD-Laufwerk (D:)** Insert the installation CD-ROM in your CD-ROM drive. In our example we suppose that this is drive "D"..
2.  **setup.exe** Start the Windows Explorer and in the folder tree of your CD-ROM drive go to the installation folder D:\Install\ .
Then start the installation program by double-clicking on the SETUP.EXE symbol.

As an alternative, software installation can also be started by clicking on **START-Run...** and then entering "D:\Install\setup.exe", which must be confirmed by pressing the **OK** button.





The installation program then displays a dialog box for *L-LAS-TB-Scope* installation. This dialog box shows some general information about installation.

Click on **Next>** to start the installation




or on **Cancel** to quit the installation of the *L-LAS-TB-Scope* software.




3. 

When you click on the **Next>** button, a new dialog appears for selecting the folder where the application will be installed (destination folder).

You may accept the suggested folder with **Next>**, or you may change the installation folder as desired by clicking on the **Browse** button.



4.



Another *L-LAS-TB-Scope* Setup dialog will be displayed.

<< **Back**

Click on the **Back** button if you want to change the installation folder again.


Next >>

Click on **Next>>** to start the installation, or

Cancel

click on **Cancel** to quit the installation process.

5.



When installation is completed, a dialog box informs you about successful installation.

A new *L-LAS-TB-Scope* program group has been created under Start-All-Programs.

Finish

Click on the **Finish** button to finish the installation.

The *L-LAS-TB-Scope* software can now be started by clicking on the respective icon in the newly created program group under:

Start >All Programs > L-LAS-TB-ScopeV2.2

Deinstallation of the L-LAS-TB-Scope software:



Software

Please use the Windows deinstallation tool to remove the software.


The Windows deinstallation tool can be found under Start / Settings / Control Panel.

3 Operation of the *L-LAS-TB-Scope* software

The *L-LAS-TB-Scope* software is used for parameterizing the electronic control unit used for controlling the *L-LAS* line sensors. The measured values provided by the sensor can be visualized with the PC software, which means that the software among others can be used for adjustment purposes and for setting suitable tolerance limits for the inspection of the measuring object.

Data exchange between the PC user interface and the sensor system is effected through a standard RS232 interface. For this purpose the sensor is connected to the PC with the serial interface cable cab-las-4/PC. When parameterization is finished, the setting values can be permanently saved in an EEPROM memory of the *L-LAS-TB* control unit. The sensor system then continues to operate in "STAND-ALONE" mode without PC.

When the *L-LAS-TB-Scope* software is started, the following Windows® user interface will be displayed:



The *L-LAS-TB-Scope* CONTROL PANEL provides a great variety of functions:


- Visualization of measurement data in numeric and graphic output fields.
- Setting of the laser power for the laser transmitter.
- Setting of the polarity of the digital switching outputs OUT0, OUT1, and OUT2.
- Selection of a suitable evaluation mode.
- Presetting of setpoint value and tolerance band.
- Saving of parameters to the RAM, EEPROM memory of the control unit, or to a configuration file on the hard disk of the PC.

The following chapters provide explanations of the individual control elements of the *L-LAS-TB-Scope* software.

3.1 Control elements of the L-LAS-TB-Scope software:




Changes that are made in the function fields described below only become active in the hardware of the L-LAS-TB sensor when the *SEND* button is pressed!



POWER:


In this function field the laser power at the laser transmitter unit of the line sensor can be adjusted by using the slider or by entering a numerical value in the corresponding input field.



V-THD (Video Threshold):


In this function field a threshold can be set by entering a numerical value. With this threshold the measurement values can be derived from the intensity characteristic (video signal) of the CCD line. For this purpose the intersecting points between the intensity profile (red curve) and the adjustable video threshold (green horizontal line) are calculated and stored.

The x-value of the respective intersecting point is assigned to a pixel on the CCD line. The measurement value can be calculated from this information and from the known distances of the pixels on the CCD line. The intersecting points between intensity profile and video threshold that are provided by this method are hereinafter referred to as edges.




TOLERANCE-VALUE:

In this input field a tolerance value for the tolerance window can be set by entering a numerical value or by clicking on the arrows. The tolerance window is applied symmetrically around the setpoint value (TEACH-VALUE).





The tolerance value that is currently set at the sensor is shown in a numerical display field below the graphic display area. If the TOLERANCE potentiometer at the sensor housing is activated, the value for the tolerance that is set at the potentiometer is displayed.



TOL-DIFF-CHECK:

In this input field a tolerance value for the differential checking of two subsequent measurement values (scans) can be preset by entering a numerical value or by clicking on the arrows. If the current measurement value (*MvalNew*) differs from the previous measurement value (*MvalOld*=mean value of the AVERAGE ring memory) by more than the threshold (number of pixels) that is set here, a short high pulse (duration approx. 100ms) is provided at the error output OUT2. The two red LEDs at the housing simultaneously blink for a short time.

if ($|MvalNew - MvalOld| > TOL_DIFF_CHECK$) then ERROR



HW-MODE (Hardware Mode):

The TOLERANCE potentiometer and the TEACH/RESET button at the housing of the *L-LAS-TB sensor* can be activated (ENABLE) or deactivated (DISABLE) by clicking on the respective item in the list selection field.

The TOLERANCE potentiometer allows the presetting of a tolerance window around the setpoint value. If the function field is set to ENABLE ALL or ENABLE TOL-SET, it is not possible to enter numerical values in the TOLERANCE-VALUE input field of the PC software.

DISABLE ALL

Both the hardware TEACH/RESET button and the TOLERANCE potentiometer at the sensor housing are deactivated.

ENABLE ALL:

The TOLERANCE potentiometer at the housing is activated.

(clockwise turning increases the tolerance bandwidth)

The TEACH/RESET button at the housing is activated.

Button pressed for a short time ($t < 0.5s$) : RESET.


Button pressed for a long time ($t > 1.5s$) : TEACH.

ENABLE BTN:

Only the TEACH/RESET button at the housing is activated.

ENABLE TOL-SET:

Only the TOLERANCE potentiometer at the housing is activated.



EVAL-MODE:

This list selection field serves for setting the evaluation mode at the *L-LAS-TB sensor*. Depending on the evaluation mode that is currently set, the edges created from the video signal (intensity profile) of the CCD line will be assessed differently.

L-EDGE:

The 1st edge (left edge) of the CCD line's intensity profile is used as measurement value.

R-EDGE:


The 2nd edge (right edge) of the CCD line's intensity profile is used as measurement value.

WIDTH:

The difference between the second and the first edge is used as measurement value: $WIDTH = R-EDGE - L-EDGE$


CENTER:

The mean value of the first edge and the second edge is used as measurement value: $CENTER = (L-EDGE + R-EDGE) / 2$



ANA-MODE (analog output mode):

A click on this function element opens a list field for the selection of the output mode of the analog voltage at the *L-LAS-TB sensor* (pin8/red 8-pole SPS/POWER socket).



AVERAGE:

In this function field, averaging at the *L-LAS-TB sensor* can be set by performing a mouse-click on the input field or by clicking on the arrow.



POLARITY:


In this function field the output polarity at the *L-LAS-TB sensor* can be set with a mouse-click on the edit box or by clicking on the respective arrow button. The *L-LAS-TB sensor* has 3 digital outputs (OUT0, OUT1, OUT2) through which error states can be sent to the PLC.

DIRECT:

In case of an error, the respective digital output is set to +Ub (+12DC ... +32VDC)
(red LED on).

INVERSE:

In case of an error, the respective digital output is set to the reference potential (GND,0V).
(red LED off).



RS-232-MODE:

This function field is used for setting the operating mode of the RS232 interface at the *L-LAS-TB sensor*.

STATIC:

The RS232 interface of the L-LAS sensor returns a single data frame upon the request of the PC/PLC (cf. RS232 communication protocol).

CONTINUOUS:


When the operating mode is set to continuous, the micro-controller of the *L-LAS-TB sensor* continuously sends measurement data through the RS232 interface. The time interval between the cyclic sending of data frames can be set with a HyperTerminal command. This mode serves for data transfer to the Windows HyperTerminal program (cf. data exchange with HyperTerminal).



There will be data exchange errors, if the RS232 mode is set to **CONTINUOUS** and the *L-LAS-TB-Scope* software is worked with at the same time.


Remedy:

Deactivate automatic measurement data transfer by selecting STAT and activating this selection with SEND!




E-BEG:

Numeric input field for entering the beginning of evaluation. The CCD line is evaluated starting from the pixel that is set here (Evaluation-Begin). (Default value = 1).



E-END:

Numeric input field for entering the end of evaluation. The CCD line is evaluated up to this pixel. Pixels on the right side of the pixel value that is set here will not be evaluated.




Teach Edge:


With a click on the Teach button the current edge information is stored as a teach value to the RAM memory of the *L-LAS-TB* sensor. Depending on the evaluation mode that has been set (E-MODE), the left edge, the right edge, the width (WIDTH), or the center position (CENTER) will be stored as a teach value in the RAM memory of the *L-LAS* sensor.

When the teach process is completed, the green LED at the housing of the *L-LAS-TB* sensor quickly blinks 3 times.


The teach process also can be started by means of the TEACH/RESET button at the housing (pressing the button for $t > 1.5s$) or by way of a high pulse at digital input IN1/yellow/pin4 ($t > 1.5s$).



It is furthermore possible to set the current teach value (setpoint value) by entering a numerical value in the numeric input field. The teach value that is set by this method will only be activated at the L-LAS-TB sensor after a click on the SEND button.



The newly taught setpoint value can be read out through the serial interface by clicking on the GET button.



The new teach value is then shown in the TEACH display field.




OP-MODE (Operation Mode):

Depending on the CCD line that is used in the L-LAS-TB sensor, this function field may offer two different setting possibilities:

(I): Binary switch for setting the operating mode at the CCD line.

ADC-CNV: Analog/digital conversion of the video pixel information (8-bit)

DIG-CMP: Information acquired by means of a digital comparator at the pre-amplifier module of the CCD line. Advantage: higher scan rate.



(II): Binary switch for setting the gain at the CCD line.

| | |
|--------------------------------------|------|
| <input checked="" type="radio"/> RAM | SEND |
| <input type="radio"/> EEPROM | GET |
| <input type="radio"/> FILE | |

SEND

GET

PARAMETER TRANSFER:

This group of function buttons is used for transferring parameters between the PC and the *L-LAS-TB control unit* through the serial RS232 interface.

SEND:

When the SEND button is clicked, the parameters currently set on the user interface are transferred to the *L-LAS-TB control unit*.

The target of data transfer is determined by the selected radio-button (RAM, EEPROM, or FILE).

GET:

When the GET button is clicked, the setting parameters are transferred from the *L-LAS-TB control unit* to the PC and are updated on the user interface. The source of data transfer again is determined by the selected radio-button:

RAM:

The currently set parameters are written to the volatile RAM memory of the *L-LAS-TB control unit*, or they are read from the RAM and transferred to the PC. Please note: The parameters set in the RAM will be lost when the power supply at the *L-LAS-TB control unit* is turned off.


EEPROM:

The currently set parameters are written to the non-volatile EEPROM memory of the *L-LAS-TB control unit*, or they are read from the EEPROM and transferred to the PC. Parameters that are saved in the EEPROM will not be lost when the power supply is turned off.

If parameters are read from the EEPROM of the *L-LAS-TB control unit*, these must be written to the RAM of the *L-LAS-TB control unit* by selecting the RAM button and then clicking on SEND. The *L-LAS-TB control unit* then continues to operate with the set RAM parameters.

FILE:

When the FILE radio-button is selected, a click on the SEND/GET button opens a new file dialog on the user interface. The current parameters can be written to a freely selectable file on the hard disk of the PC, or parameters can be read from such a file.



FILE dialog window:

The standard output file for the parameter values has the file name "LLASpara.dat".


The output file can be opened e.g. with the standard Windows "Editor" program.

3.2 Numeric and graphic display elements:



VIDEO-button:

After a click on the VIDEO button, the intensity profile measured at the CCD receiver is transferred to the PC and is shown as a red curve in the graphic display window.



The y-axis shows the analog signals of the individual pixels. The analog values (video signals) of the CCD line are converted by means of an AD converter with 10-bit resolution, which results in a y-axis value range of 0 .. 255.

The currently set video threshold (V-THD) is shown as a green horizontal line in the graphic display. The edge values (pixels) are derived from the intersecting points of the intensity profile (red line) with the video threshold (green line).

The x-axis shows a virtual representation of the individual pixels of the CCD line (for example: Pixel 1 .. 1536).

Because of the limited data transfer rate of the serial interface (19200 Baud/s) the graphic display window can only be updated every second.

Beneath the graphic display window there is another display element that shows the currently detected shadowed areas and the illuminated areas of the CCD line. Furthermore the currently detected edge position is indicated in this display element by way of a black circular cursor. A green horizontal bar represents the width of the tolerance band that is currently set around the teach value.



E-LEFT:

Numeric display field that shows the current left edge position.



E-RIGHT:

Numeric display field that shows the current right edge position.



M-VALUE:


Numeric display field that shows the current measurement value (depending on the set evaluation mode).

The left numeric display field shows the current measurement value in pixels, whereas the right display field shows the measurement value converted into micrometers.



RUN:

After a click on the RUN button, the current measurement data will be transferred from the *L-LAS-TB sensor* to the PC via the serial interface.



After a click on the RUN button the current measurement value is shown in the graphic display window in "scroll mode". In the form of a red curve the measurement values pass through the graphic display window from the right to the left.

The division of the y-axis corresponds with the pixels at the CCD line, or with the virtual number of sub-pixels of the line. In the graphic display the current measurement value (M-VALUE=717) is shown at the right end at the x-value of 100.

In addition, the current tolerance window is represented by two horizontal green lines that are applied symmetrically around the setpoint value.

In "RUN mode" the length of the data frame is limited to 18 words (36 bytes), which allows faster updating of the numeric and graphic display elements.

Compared to "DATA mode", data transfer through the serial RS232 interface therefore does not take so much time (in DATA mode the intensity information for every pixel must be transferred).

3.3 Serial RS232 data transfer:

RS232 COMMUNICATION:

- Standard RS232 serial interface without hardware-handshake.
- 3-line-connection: GND, TXD, RXD.
- Speed: 19200 baud, 8 data bits, no parity bit, 1 stop bit in binary mode, MSB first.




Attention !

The stable function of the RS232 interface (status message after program start) is a basic prerequisite for data transfer between the PC and the *L-LAS-TB control unit*. Due to the low data transfer rate of the serial RS232 interface (19200 bit/s) only slow changes of the analog values can be observed in the graphic display at the PC. In order to guarantee the maximum switching frequency of the *L-LAS-TB control unit* it is therefore necessary to stop the data exchange during the normal monitoring process (click on the STOP button).



CONNECT:

When the software is started, it attempts to establish a connection to the *L-LAS-TB control unit* through the standard COM1 interface. If connection could be established successfully, the current firmware version is displayed in the status line.



The serial connection between the PC and the *L-LAS-TB control unit* could not be established, or the connection is faulty.

In this case it should first be checked whether the *L-LAS-TB control unit* is connected to the power supply, and whether the serial interface cable is correctly connected to PC and *L-LAS-TB control unit*.

If the number of the serial interface that is assigned at the PC should not be known, interfaces COM1 to COM9 can be selected by using the **CONNECT** drop-down list.



If there is an "Invalid port number" status message, the selected interface, e.g. COM2, is not available at your PC.



If there is a "Cannot open port" status message, the selected interface, e.g. COM2, may already be used by another device.

3.4 L-LAS-TB-Scope as an aid for sensor adjustment:




VIDEO:

After a click on the VIDEO button, the fine adjustment between the L-LAS transmitter unit and the receiver can be observed in the graphic display window. Because of the limited data transfer rate of the RS232 interface the display window can only be updated every second.



STOP:


A mouse-click on the STOP button stops the data transfer between the L-LAS-TB control unit and the PC.



Optimal adjustment:


In the graphic display window the intensity profile is shown as a red curve. The numerical values 1 ... 1024 on the x-axis represent the individual pixels of the CCD line. The analog values of the CCD line are converted by way of an AD converter with 10-bit resolution, which results in a y-axis value range of 0 .. 1023.

As can be seen in the picture on the left, the CCD pixels 1 to 1024 are uniformly illuminated by the transmitter beam.



Wrong adjustment - right:


The transmitter beam no longer sufficiently illuminates the pixels at the right end of the CCD line. The alignment of the laser transmitter unit or the CCD receiver unit must be readjusted in such a way that the pixels at the right end are illuminated again.



Wrong adjustment - left:

The transmitter beam no longer sufficiently illuminates the pixels at the left end of the CCD line. The alignment of the laser transmitter unit or the CCD receiver unit must be readjusted in such a way that the pixels at the left end are illuminated again.

3.5 L-LAS-TB-Scope as aid for transmitter power adjustment:



POWER:

In this function field the laser power at the laser transmitter unit of the *L-LAS-TB sensor* can be set by using the slider or by entering a numerical value in the respective input field.



The laser power at the transmitter unit of the *L-LAS-TB sensor* is only updated when the **SEND** button is pressed.



VIDEO:

After a click on the VIDEO button, the current intensity profile is transferred from the *L-LAS-TB sensor* to the PC and is shown in the graphic display window. When the VIDEO function is active, the sensor's laser power can be changed (press the **SEND** button), and the effect of such a change can be observed in the intensity profile.




Optimal adjustment:

In the graphic display window the intensity profile is shown as a red curve. Through the complete CCD line the intensity characteristic lies above the video threshold (green line).

In the shadowed area the intensity characteristic is at low ADC values (offset <120).

In the shadowed areas the intensity characteristic does not show any sporadic "spikes".




Transmitter power too high:

The transmitter beam overloads individual pixels of the CCD line. There are sporadic short upward "spikes" in the shadowed areas.

If such "spikes" intersect with the green horizontal video threshold, there will be incorrect measurements!

Remedy:

Reduce the laser power in steps, until such "spikes" in the shadowed area do not occur any more.



Transmitter power too low:

The intensity profile of the CCD line completely lies under the video threshold (green horizontal line).

The *L-LAS-TB sensor* does not detect any edges (bright/dark transitions, i.e. intersections between red curve and green video threshold) in the image of the beam.

Remedy:

Increase the laser power in steps, at the same time observing the intensity characteristic, until the red curve (intensity profile) of pixel 1 to pixel 1024 lies above the video threshold.


4 Evaluation modes

4.1 LEFT-EDGE



L-EDGE:

The first detected edge in the intensity profile of the CCD line is evaluated.



The criterion for edge detection is the transition between illuminated and shadowed areas in the intensity characteristic of the CCD line.

The one pixel of the CCD line at which this bright/dark transition takes place can be determined from the intersection between the video threshold (green horizontal line) and the intensity characteristic (red curve).

In the example picture on the left, the first bright/dark transition is detected at pixel no. 488.


The current measurement value M-VALUE = E-LEFT is shown in the red numeric display element.

4.2 RIGHT-EDGE



R-EDGE:

The second detected edge in the intensity profile of the CCD line is evaluated.



The one pixel of the CCD line at which the second bright/dark transition takes place can be determined from the intersection between the video threshold (green horizontal line) and the intensity characteristic (red curve).

In the example picture on the left, the second bright/dark transition is detected at pixel no. 668.

The black dot-shaped cursor beneath the graphic display window represents the current right edge (R-EDGE) of the shadowed area.



The current measurement value M-VALUE = E-RIGHT is shown in the red numeric display element.

4.3 WIDTH



WIDTH:

The difference between the second edge and the first edge in the intensity profile of the CCD line is evaluated.



The two pixels where the bright/dark transition occurs can be determined from the two intersections between the video threshold (green horizontal line) and the intensity characteristic (red curve).

In the example picture on the left, the second bright/dark transition is detected at pixel no. 668, and the first bright/dark transition at pixel no. 488.

By forming the difference, the result is

$$WIDTH = E_RIGHT - E_LEFT$$


The current measurement value M-VALUE = WIDTH is shown in the red numeric display element.

4.4 CENTER



CENTER:

The mean value of the first and the second edge is used as measurement value: $CENTER = (R-EDGE + L-EDGE)/2$



The two pixels where the bright/dark transition occurs can be determined from the two intersections between the video threshold (green horizontal line) and the intensity characteristic (red curve).

In the example picture on the left, the second bright/dark transition is detected at pixel no. 668, and the first bright/dark transition at pixel no. 488.


By forming the mean value, the result is


$$CENTER = \frac{(E_RIGHT + E_LEFT)}{2}$$

The current measurement value M-VALUE = CENTER is shown in the red numeric display element.

5 Two-point calibration

(to be supplemented)

| | |
|---|--|
|  | <p>Nach Anklicken dieser Taste wird ein neues Graphik-Funktionsfenster eingeblendet. Aus diesem Fenster kann eine Zweipunkt-Kalibrierung am CCD-Zeilensensor durchgeführt werden. Ferner sind im oberen Teil des PARA II Fensters (CCD-Settings & Calibration) aktuelle Parameter der CCD-Zeile angezeigt.</p> |
|---|--|



CCD-Settings & Calibration

CCD-SENSOR: 1024 pixel, 7.8µm pixel-pitch, 8.0mm working range

Activate CCD-CALIBRATION

STEP 1 ☒ On/Off

Place small object into the center of the L-LAS light measuring section.
 Enter the DIAMETER-1 [µm] of the object.

Accept Object 1 PIXEL DIAMETER-1 [µm]

0 10000

STEP 2 ☐ On/Off

Place big object into the center of the L-LAS light measuring section.
 Enter the DIAMETER-2 [µm] of the object.

Accept Object 2 PIXEL DIAMETER-2 [µm]

0 20000

Calculate Calibration: $Y = A \cdot X + B$

SLOPE-VALUE A INTERSECTION B


8.000 0.000 0.0 0.0

SAVE NEW VALUES EXIT CALIBRATION

CCD-CALIBRATION


6 Annex

6.1 Laser warning

| LASER WARNING | |
|--|--|
| <p>Solid-state laser, $\lambda=670$ nm, 1mW max. optical power, laser class 2 acc. to EN 60825-1</p> <p>Therefore no additional protective measures are required for the use of these laser transmitters.</p> | |
|  | <div style="border: 2px solid black; background-color: yellow; padding: 10px; width: fit-content; margin: 0 auto;"> <p>Nicht in den Strahl blicken Laser Klasse 2</p> </div> |

6.2 Function of the TEACH/RESET button


The housing of the *L-LAS* sensor features a pushbutton with two functions:



RESET function:

When the button is pressed for a short time ($t < 750\text{ms}$), the current maximum and minimum values are reset.

A hardware/software RESET is not performed!




TEACH function:

When the button is pressed for a longer time ($t > 1.5\text{s}$), the current edge coverings are stored as teach value in the RAM memory. When the teach process has been performed successfully, the green LED blinks three times.

6.3 Function of the tolerance potentiometer:


The housing of the *L-LAS-TB* sensor features a potentiometer for setting the tolerance band width.



TOLERANCE potentiometer:

Turning the potentiometer clockwise increases the tolerance band width.



Turning it counter-clockwise decreases the tolerance band width.



The potentiometer must be activated (switch position **ENABLE**) in order to use it for setting the tolerance band width at the *L-LAS-TB* sensor).

6.4 Function of digital inputs IN0 and IN1

The L-LAS sensor has two digital inputs IN0 and IN1 that can be contacted through the 8-pole female connector (type Binder 712).




| Pin: | Color: | Assignment: |
|------|--------|-------------------------------|
| 1 | white | 0V (GND) |
| 2 | brown | +12VDC ... +32VDC |
| 3 | green | IN0 (EXT TRIGGER) |
| 4 | yellow | IN1 (TEACH/RESET) |
| 5 | gray | OUT0 (-) |
| 6 | pink | OUT1 (+) |
| 7 | blue | OUT2 (OK) |
| 8 | red | ANALOG (0...10V or 4...20mA)) |

DIGITAL INPUT IN1 (pin4/yellow):


RESET function:

When a **HIGH**-pulse of less than **750 ms** duration is applied, the **RESET** function is performed at the *L-LAS-TB* sensor. This resets the current maximum and minimum values. It does not perform a hardware/software RESET! When a RESET-pulse has been detected, the green LED blinks shortly two times.




TEACH function:

When a **HIGH**-pulse of more than **1.5s** duration is applied, the **TEACH** function is performed at the *L-LAS-TB* sensor. When a TEACH pulse has been detected, the green LED at the housing blinks shortly three times.




6.5 Connector assignment



At the housing of the *L-LAS-TB* sensor there is a female connector for power supply connection (8-pol. type Binder 712) and a second female connector for connecting a serial RS232 connecting cable (4-pol. type Binder 707).

RS232 connection to the PC:


4-pole M5 female connector type Binder 707



| Pin: | Assignment: |
|------|---------------|
| 1 | not connected |
| 2 | 0V (GND) |
| 3 | RxD |
| 4 | TxD |



Connecting cable:

cab-las4/PC (length 2m, cable jacket: PUR)



Interface to PLC/power supply:

8-pole female connector type Binder 712



| Pin: | Color: | Assignment: |
|------|--------|------------------------------|
| 1 | white | 0V (GND) |
| 2 | brown | +12VDC ... +32VDC |
| 3 | green | IN0 (EXT TRIGGER) |
| 4 | yellow | IN1 (TEACH/RESET) |
| 5 | grey | OUT0 (-) |
| 6 | pink | OUT1 (+) |
| 7 | blue | OUT2 (OK) |
| 8 | red | ANALOG (0...10V or 4...20mA) |

Connecting cable:

cab-las8/SPS (length 2m, cable jacket: PUR)

